

Warranty



To receive after sales service, have the following ready when you contact our branches

- 1. Name of the product
- 2. Model number of the product
- 3. The area of problem
- 4. Phone number and address at which you can be contacted.

Warranty Card

PRODUCT	
MODEL	
DATE PURCHASED	
WARRANTY PERIOD	
AGENCY	
AGENCY ADDRESS	

☉ **KOCOM** Warranties the original purchaser of this product as follows.

- 1) This product is produced under strict quality control and inspection procedures.
- 2) If this product breaks down during proper use as a result of product defect, KOCOM will repair it within one year from date of purchase free of charge.
- 3) The following cases will be subject to charge, even during warranty period:
 - a. Breakdown during transport, or through careless treatment, by consumer.
 - b. Breakdown caused by unauthorized repair, or system modification.
 - c. Breakdown caused by natural disaster or power disorder.


KOCOM®

DIRECT INTERPHONE






KIP-601PM / KIP-601PS MANUAL FOR OPERATION AND INSTALLATION

Features


- Perfect for private conversations
- Delightful sound
- Easy wiring with 2 lines of polarity
- Power : D.C 6V (main only) 4 Piece of 1.5V batteries (one side insert)
- Range: ϕ 0.65mm wire, 300m line
- Easily mounted on wall, desk




Precautions for Operation

 <p>As this device consists of precise electronic components, and high voltage is generated internally, do not attempt to disassemble.</p>	
 <p>Do not drop indoor station, and avoid strong impact.</p>	
 <p>Keep away from humidifier and stove. High temperature and humidity can cause malfunction</p>	
 <p>When cleaning, never use wet hands, volatile benzene or paint thinner.</p>	 <p>Maintain the product clear by frequently cleaning with soft cloths</p>


Name of Each Part




How to operate (Instruction for operating)



When a visitor pushes the main station bell,




The sub station is ringing.




Pick up the handset and communicate with a visitor. After end of communication, return the handset where it is locked

Wiring Diagram



Installation



- A- Choose a place on the wall where you want to hang the Indoor station.
- B- Fasten the wall hanger on the wall.
- C- Indoor station can be hung on the wall hanger easily now.

Specifications

Description	KIP-601PM	KIP-601PS
Electric source	DC 6V	Power from Main (KIP-601PM)
Consumption	Un Load: 0.2mW, In Load: 1W	Un Load: 0.2mW, In Load: 1W
Signal Sound	Electronic Chime	Electronic Chime
Wiring Range	2 Wired polarity 300m(φ 0.65mm)	2 Wired polarity 300m(φ 0.65mm)