


Wiring Diagram and Installation of 2 Wire Color Door Camera Series


※ Please check the Model Name of your door camera.

KC-MC22



CAMERA

[KC-MC22]






DC Electric Door Lock

- ① RED : LINE 1 } Monitor Connection
- ② ORANGE : LINE 2 } Connection
- ③ BLACK : DOOR 1 } Door Lock
- ④ BROWN : DOOR 2 } Connection
- ⑤ GREEN : FG


※ Only one Electric door lock should be connected to the door camera or monitor.

[KCV-352]




KC-MC11

Surface mount type




※ When using Angle Supporter, if Main Body Screw(4x18) does not fit, please use Spare Screw(4x20).

Flush mount type



CAMERA




[KC-MC11]



DC Electric Door Lock

※ Only one Electric door lock should be connected to the door camera or monitor.



[KCV-352]



Wiring Diagram and Installation of 2 Wire Color Door Camera Series

※ Please check the Model Name of your door camera.

KC-C62



KC-MC32

